

### STEP 1: IMPORT

The EDGE makes it easy to start a new estimating job. Simply import your architectural blueprints or hand drawing, set the takeoff screen scale, and you're ready to go.



## STEP 2: TAKEOFF

Make detailed measurements directly on screen by clicking with your mouse. The EDGE is smart enough to know what units to use based on what's being measured and automatically calculates material quantities for you.



### STEP 3: ADJUST

Adjust the material quantity, waste material, taxes, and bond rates, then modify labor rates or change crew sizes. All edits are instantly adjusted throughout the entire estimate.



### STEP 4: BID

In-depth reporting keeps you in control of your final bid. Reports are customizable and can be used on the job site to better communicate, order materials, review labor costs, help create a budget, or just get a recap of all costs.



# ESTIMATE YOUR NEXT DURO-LAST® PROJECT WITH THE EDGE™

Duro-Last is proud to collaborate with Estimating Edge, the technology provider for The EDGE<sup>TM</sup> Estimator, a cloud-based estimating solution and a job site project management app called EDGE On Site<sup>TM</sup>.

This custom version of The EDGE™ comes prepopulated with Duro-Last products, part numbers, and pricing. With the click of a button, you can immediately start creating a new bid for your next Duro-Last project! Plus, updates to products and prices are easily managed by users, significantly reducing software maintenance. And even better, you can export your project material lists directly to Duro-Last, improving your ordering efficiencies and reducing errors.

NOTE: Verification and accuracy of product pricing and bid estimates are the responsibility of the contractor/user.





# **BEYOND THE BID**



# **EDGE On Site™**

STEP 1: ACTIVATE STEP 2: TRACK

EDGE On Site brings your EDGE estimate to the job site. Simply download the EDGE On Site app to access the original estimate on your mobile device, including any blueprints and project details.

What's been built in the field? With virtually no data entry field personnel, simply select takeoff "shapes" as they are completed.

#### STEP 3: UPDATE

Change orders? When a new change order has been created in The EDGE, your field personnel are automatically notified.

### STEP 4: REPORT

the actual estimate, takeoff and any change

orders with virtually zero data entry.

EDGE On Site shows you exactly how production matches the original estimate. Now you can find and correct cost overruns before they get out of control. And best of all, you can see how to make this job and your next one more profitable.



Saginaw, MI | Grants Pass, OR | Sigourney, IA | Jackson, MS | Carrollton, TX | Ludlow, MA

Contact your Duro-Last Sales Representative today to learn more about The EDGE and how you can put it to work on your next Duro-Last project.

800-248-0280 duro-last.com